

Log FAR 1.1 Flight Time 1

To use APDL to log flight time according to FAR 1.1, ensure that "Enable Taxi Time" is turned on in Settings > General under [Misc](#). Then enter the time your aircraft first moved under its own power in the [Taxi Time](#) row on [Leg View](#).

FAR 1.1 FLIGHT TIME	
Taxi Time	Taxi Time