

# FAR Error Checking

Automatic error checking is built into Logbook Pro to prevent common errors such as entering a secondary time entry that exceeds that of the flight. Error checking occurs (if optioned in the [Flight Log Options](#) area) after every flight entry validating the minimum fields have been logged (Date, Type, Ident, Route, Duration (or Sim)) and that no other time field exceeds that of the Duration.